

# INSTRUCTIONS: J2-WCOV TWO CIRCUIT TRACK WIREWAY COVER

## CAUTION

- Always turn off power at main switch prior to installation to prevent electrical shock.

The J2-WCOV plastic wire way cover fits the WAC 2-circuit track and hides the live end connection on suspended track.

1. Install the suspension rod assembly to the junction box by routing 12 gauge wires through the cross bar, canopy, and suspension rod. Allow sufficient wire length for connection at lower end. The length of the suspension rod plus 12" is adequate and may be trimmed as needed latter.
2. Slip the wire way cover up over the lower shoulder of the suspension rod. Loosely thread the hex nut to the bottom of the suspension rod.
3. Position the suspension bracket as shown in the diagram and slide it in from the end of the track, to the pre-drilled hole. Secure with cap nut, and square head screw (supplied).
4. Install the live end connector. Remove it's cover and secure wire connections ( see instructions supplied with live end connector).
5. The suspension bracket can now be installed to support the track. From the open groove in the bracket slide it over the hex nut and fully tighten the nut. Bring the wire way cover over the shoulder of the suspension rod, and press in place.

